



**EXPERT
SECURITY**
& COMMUNICATIONS


OFFICE Copy

Lorimer Business Park
Unit 6, 11 Sabre Drive
Port Melbourne VIC 3207
Telephone: 03 9681 8899
Facsimile: 03 9681 8898
Email: enquiries@expertsecurity.com.au
ACN: 072 624 321 ABN: 91 072 624 321



Hallmark Apartments

Operating Instructions for the BPT Audio Video Intercom System




Entry Panel

Entry Panel

To call an apartment from this panel
- dial the apartment number then
press the (bell) button

Your visitors can call your apartment from a call panel located at the building entrances. When called, the system will transmit an electronic tone to your apartment intercom.



Audio Video Intercom

RECEIVING A CALL

Your apartment intercom will emit an electronic tone when your apartment number is dialed from any call panel by a visitor. Also your LCD screen will automatically activate enabling you to view your visitor. **(no picture if called from carpark driveway).**

ACTIVATING AUDIO COMMUNICATION

There are 2 modes of audio communication possible when receiving a call

MODE 1 - Handsfree mode - press the audio control button once only (momentarily), this will activate the audio (RED light will turn ON), you can now speak & listen to your visitor. To switch the audio OFF (or mute) press the audio control button once again (momentarily) or the system will automatically switch OFF in approx 40 seconds.

MODE 2 - Talk and Listen mode - press and hold the audio control button down, this will activate the audio to the entry panel only (1 way audio and the RED light will turn ON) then release the audio control button to listen to the visitor only. Repeat this procedure as necessary. The system will automatically switch OFF after approx 40 seconds.

GRANTING DOOR AND LIFT ACCESS TO YOUR VISITOR

To grant your visitor access into the building, press the DOOR RELEASE CONTROL button once (button with a KEY symbol). This function will unlock the door for approx 5 seconds. Repeat the same procedure when your visitor calls from the carpark driveway entry. To grant your visitor access to your apartment level only via lift car/s press the LIFT RELEASE button (button with the ":" symbol beside it). This function will de secure the lift car/s for your level only for approx 30 seconds.